

IMPORTANT!





To ensure long and reliable service from your Unbreakable® Telescopic Umbrella do not strike objects with the section marked on the photo by the circle. Moreover, strikes with this section are much weaker than those with the handle or the part of the rod just below the handle.

See the reverse side for instructions how to replace a canopy of your Unbreakable® Telescopic Umbrella.


Unbreakable® Telescopic Umbrella—Canopy Replacement



1. To remove the old canopy unscrew the metal tip and then the plastic nut at the top of the canopy.





2. Push out the pin holding the retaining plug.



3. Pull out the retaining plug with its rubber gasket.



4. Pull out the telescoping shaft from the canopy.



5. Open the replacement canopy, remove the bubble protector from the uppermost tube and fold the replacement canopy. Now you may put the new canopy on the shaft, following the above steps in reverse order.